HOW TO USE GUIDE

Pro Heater

3kW free-standing electric heater for space heating



SUPPLY	HEATING	CONNECTION	MOUNT
230V 1Ph	3kW	13A UK Plug	Free Standing

QUICK START

1. Stand the heater on its feet on a level, dry surface with space around it for airflow.
2. Check the power lead and plug before connecting the heater.
3. Plug into a suitable 230V, 13A socket.
4. Switch on using the controls fitted to the unit and allow free airflow around the heater.
5. When finished, switch off and unplug. Allow the casing to cool before moving or storing.

BEFORE USE

- Place the heater free-standing on a stable, level floor.
- Confirm a suitable 230V single-phase supply is available.
- Inspect the fitted UK plug and lead for visible damage.
- Keep the top and ventilation openings clear.

General operating guidance: always follow the labels and controls on the supplied unit, plus your site electrical and safety procedures.

DO

- Use the heater free-standing on a stable floor.
- Keep the top and vents clear.
- Unplug before moving or cleaning.

DON'T

- Do not cover the heater.
- Do not use around water.
- Do not trap or damage the cable.

0203 062 4123 sales@hvacrentals.co.uk www.hvacrentals.co.uk Lower Assendon, Henley-on-Thames, RG9 6AN