HOW TO USE GUIDE

The Mini Sun 3kW Electric Portable Infrared Heater

Portable quartz-halogen infrared heater with medium / high heat settings



SUPPLY	HEATING	CONNECTION	SETTINGS
240V	3kW	13A UK Plug	Medium / High

QUICK START

1. Position the heater upright with the guarded face directed toward the area requiring heat.
2. Keep the area in front clear and ensure the unit cannot be covered or obstructed.
3. Plug into a suitable 240V, 13A socket.
4. Switch on and select medium or high heat using the controls fitted to the heater.
5. Switch off and unplug after use. Allow the guard and quartz-heater area to cool before moving.

BEFORE USE

- Place the heater upright on its castors on a stable surface.
- Confirm a suitable 240V supply is available.
- Inspect the 13A plug, lead, guard and heater for visible damage.
- Keep a clear, unobstructed area in front of the heater.

General operating guidance: always follow the labels and controls on the supplied unit, plus your site electrical and safety procedures.

DO

- Keep the heater upright on its castors.
- Point the guarded face toward the occupied area.
- Allow the unit to cool before moving.

DON'T



Do not cover the heater.



Do not use around water.



Do not touch the hot guard / heater area.

0203 062 4123 sales@hvacrentals.co.uk www.hvacrentals.co.uk Lower Assendon, Henley-on-Thames, RG9 6AN